



## Manual for Gregory Hall Room 001


If the system is not working correctly reboot the entire system by turning off the console and turning it back on.



BluRay- Dvd Player/VHS Player Location - in the podium below the keyboard drawer.



- 1.** Turn on the display
- 2.** Turn off the display
- 3.** Adjust the volume - This will adjust the volume for all the devices in use.
- 4.** Mute the display - This hides the projector display but not on the computer
- 5.** Unmute the display - Turns off the “display mute”
- 6.** Mute - temporarily mute all audio
- 7.** Mac - displays the Mac Mini on the display
- 8-9.** HDMI/VGA - displays a device that is plugged into those ports.
- 10-11.** Blu-Ray/VCR - displays the respective device.
- 12.** HDMI and VGA port



**Please, remember to shut down the system and press DISPLAY OFF when finished.**