





Manual for Gregory Hall Room 003

If the system is not working correctly reboot the entire system by turning off the console and turning it back on.



BluRay- Dvd Player/VHS
Player Location - in the
podium below the keyboard
drawer.

1. Turn on the display
2. Turn off the display
3. Adjust the volume - This will adjust the volume for all the devices in use.
4. Mute the display - This hides the projector display but not on the computer
5. Unmute the display - Turns off the “display mute”
6. Mute - temporarily mute all audio
7. Mac - displays the Mac Mini on the display
- 8-9. HDMI/VGA - displays a device that is plugged into those ports.
- 10-11. Blu-Ray/VCR - displays the respective device.
12. HDMI and VGA port



Please, remember to shut down the system and press **DISPLAY OFF** when finished.